


# KEPLER PHOTOMETER

## Primary Mirror Assembly

### FEA Prediction and Measured Cryo Figure



**John W. Zinn, P.E.**  
Senior Mechanical Engineer  
L-3 Communications, Brashear  
Pittsburgh, PA 15238




## Overview

Accurately predicting optical figure at cryogenic temperatures is difficult due to the following challenges:


- Must quantify variations in material properties, including spatial distribution
- Comprehensive material testing can aid in understanding adhesive behavior, but it remains difficult to accurately implement measured data
- FEA modeling needs to be cost effective and accurate, thus requiring a balance in model refinement

This presentation discusses cost effective methods used by L-3 Brashear to predict the Kepler PMA final cryo figure at -60 °C within 8% of the measured figure.



# L-3 Communications Brashear Role on Kepler

## Responsible for Primary Mirror Assembly: Concept, Design, Fabrication, and Testing




- Design of 1.4m CA, lightweight, ULE, frit-bonded mirror – includes reinforced primary and alternate bonding sites
- Design and analysis of hexapod support structure – carbon fiber struts with titanium cross flexures
- PMA material selection & characterization
- PMA FEA analysis and figure predictions
- Strut fabrication and bond pad installation using space qualified procedures
- Strongback support fixture, mirror handling, and related tooling
- Mirror generation, metrology, PMA vibration and environmental testing
- Mirror coating



## Key Features Which Make Kepler PMA Unique

- Systems approach to Primary Mirror Assembly design
- Accommodating broad operating temperature range and high stiffness
- Including alternate support attachment locations
- Integral design features to accommodate lifting, handling, tooling, metrology & coating






## Summary of FEA Models

### Global PMA Model


- Coarse mesh of full mirror with supports
- Limited elements for bond pad and adhesive
- Valid for stiffness estimation and global support displacements
- Used to calculate mechanical loads
- Used for figure predictions



## Summary of FEA Models

### Detailed PMA Model

- Planar representation of mirror structure around one bond pad without strut
- Accurate representation of bond pad and adhesive joint
- Provides high accuracy required for stress evaluation and local figure predictions
- A symmetric 60° slice of PM would have been more appropriate



# Keys to Accurate Cryo Predictions

## Material Characterization

*How much do material properties deviate from nominal values?*

- Characterized ULE boule CTE variations for facesheet, backsheets, and core
- Measured Invar CTE resulting from the applied heat treatment
- Measured adhesive stiffness and CTE, strain rate dependent

## FEA Model Accuracy

*Is the FEA model sufficiently detailed and refined?*

- Global model is not sufficiently refined to accurately predict magnitude of local deformations around bond pad. Use detailed model to correlate global model.
- Performed analysis with measured component thicknesses (facesheet and backsheets) rather than nominal design values

# Material Characterization

## ULE CTE Mapping

- ULE nominal CTE applied using polynomial curve from Corning
- Facesheet and backsheets CTE variation mapped along 6 radial lines
- Core CTE variation mapped as function of height at 6 points
- CTE in each element is interpolated based on position, both radius and height in core


### *Lessons Learned:*

- CTE distribution shown to be rotationally symmetric, so core samples should have been chosen radially rather than circumferentially
- Given steep variations in CTE, a finer mesh in the global model would allow smoother interpolation







# Kepler Primary Mirror CTE Mapping



CTE Distribution  
on Facesheet




CTE Distribution  
on Backsheet



# Predicted Cryo Figure Effects at -60°C due to ULE CTE Distribution Only

Kepler Glass Only -60C Cryo Figure (PTF removed) web17u5-cryoglass LC2



# Material Characterization

## Invar Properties - CTE

- Invar CTE in bond pad material is a primary influence on thermal distortion and resulting cryo figure
- Literature and manufacturer reported data show a variety of reported CTE values
- CTE can be reduced with proper heat treatment and aging process
- Also increases based on carbon content in base alloy (furnace impurities)
- Material from final machined flight bond pad tested to give highest accuracy CTE values for final figure prediction

# Material Characterization

## Adhesive Properties

- Adhesive stiffness and CTE are significant variables in cryo figure prediction
- Adhesive CTE can be easily measured and quantified
- *Stiffness represents biggest unknown*, because it varies widely with temperature, is strain rate dependent, is also dependent on bond thickness, and shows nonlinear stress-strain behavior
- Comprehensive material testing can be used to characterize stiffness, *but challenge is in accurately implementing measured values*
- Actual adhesive thermal effects quantified using an optical test



# Material Characterization

## Brashear's Optical Measurement of Adhesive Stiffness



- Uniform thickness Invar pad bonded to 6"  $\varnothing$  glass blank and thermally cycled to -60 °C
- FEA scoping analysis used to determine appropriate thickness of blank such that deflections are large enough to be interferometrically measured without exceeding limits of interferometer
- Cure shrinkage also quantified with this optical test and shown to be minimal due to no observable deformation at room temperature after initial bonding
- Using accurate glass properties, measured Invar properties, and measured adhesive CTE, *the stiffness of the adhesive is varied in the FEA model such that the resulting "power" Zernike term matches the corresponding optical measurement*
- Smaller "spherical" Zernike term not directly correlated but values track with modulus adjustments


## FEA Model Accuracy

- *Brashear's cost effective approach to FEA* uses two models – one to characterize global effect and another to capture local effects
- Global model has a coarse mesh, with a rough approximation of the adhesive and bond pad geometry
- Unrealistic to build a full PMA model with level of refinement included in the detailed model (cost prohibitive)
- Question - How do you quantify the lower accuracy of the global model in terms of predicting cryo displacements, in order to account for difference?
  - *First, verify accuracy of detailed model which serves as the standard.*


Mesh refinement of the original detailed model used to demonstrate converged stress results, giving an even higher confidence for displacement predictions.
  - *Second, need to perform results comparison using equivalent models.*

A section of the global model was generated with similar boundaries and constraints as the detailed model and both were analyzed using the same properties.

# Model Comparison



**Detailed Model**



**Global Section Model**

An equivalent section of the global model under-predicts the displacements seen in the detailed model by 37%. Both models use the “correlated adhesive stiffness” obtained earlier.


## FEA Model Accuracy

How do you adjust the global PMA model to improve its accuracy?

- Cryo displacements driven by (stiffness \* CTE) of *both* the adhesive and Invar bond pad
- Chose to increase CTE of Invar to impart the additional force needed in global model to match deflections in detailed model
- Adjusted material properties only used to obtain optical figure from global model. Final stress evaluation obtained using true physical properties in the detailed model.
- Invar CTE is well correlated to cryo displacements – a 50% increase in CTE gives a 30% increase in rms surface figure




# Comparison of Local Distortion due to Bond Pad and Adhesive Shrinkage at -60 C



## Detailed Model

0.210 waves rms, 0.827 p-v

using true physical material properties



## Global Section Model


0.210 waves rms, 0.821 p-v

correlated to match detailed model results  
using 1.5 factor applied to Invar CTE




# Predicted Cryo Figure Effects at -60°C due to Bond Pad and Adhesive CTE Only

Kepler Pad Effect -60C Cryo Figure (PTF removed) web17u5-cryopads LC2




# Final PMA Cryo Figure Prediction at -60°C





## Measured PMA Cryo Figure at -60°C

= (Horizontal Cryo -60 °C – Horizontal Ambient +28 °C) => No Polishing Residual



*Predicted rms cryo figure is only 8% less than measured figure at -60 °C.*

Source effects are not removed. RMS surface = 0.148 waves.



## Closing Remarks

- L-3 Brashear was able to get excellent agreement between measured cryo figure and prediction in a cost effective manner without extremely complex FEA models.
- Magnitude of cryo figure is affected by the bond pad size which was driven by higher launch load requirements earlier in program.
- Original plan was to conservatively cryo null 50% of the predicted error prior to bonding and environmental testing.
- Post-cryo figuring had been planned to account for remaining measured cryo figure but is not needed since the figure meets the system error budget.
- Kepler PMA has successfully completed protoflight level environmental testing, both thermal-vac and vibe, and is currently being coated.

