



Subaperture stitching interferometry for large aspheric optics

Marc Tricard and Paul Murphy

1040 University Avenue, Rochester, NY • USA
+1 (585) 256-6540 • tricard@qedmrf.com • www.qedmrf.com

Acknowledgements:

Dr. Jim Kirsch – Army RDECOM
Scott Antonille – NASA Goddard


- Motivation
- Subaperture stitching interferometer (SSI[®]): background
- Aspheric Optics: success of the SSI-A[™]
 - Non-null interferometric testing
 - Measurement results
- Large Optics: scaling the SSI[®]
- Conclusions

“If you can’t measure it, you can’t make it”

- Corollary: the quality of your measurement limits the quality of optical surface you can make
- And therefore we want our metrology to be:
 - Full aperture, for deterministic correction of the whole surface
 - Accurate, to achieve tighter optical specifications
 - High resolution, to correct edges and other small features
 - Flexible, to minimize custom tooling and lead time
- Solve needs for Aspheric Metrology
 - Increase aspheric departure measurement capability of standard Fizeau interferometer with no auxiliary nulling optics
 - Obtain accuracy comparable to CGH null
 - Obtain high lateral resolution
 - Obtain quality measurement with ordinary skill
- *Subaperture stitching can address all these needs*

Subaperture Stitching Interferometer (SSI®)


- Precision six axis machine
 - Engineered in cooperation with Schneider Opticmachines
- Standard Zygo® 4" or 6" interferometer
- QED control software: automation + advanced algorithms



SSI advantages

- Cost-effective measurement of larger apertures
- Automatic, inline calibration of systematic error
- Increased lateral resolution
- Measures mild aspheres *without dedicated nulls!*

SSI measurement process




Overview of stitching benefits

- Increased lateral dynamic range
 - Increased lateral range (large clear and/or numerical aperture)
 - Can improve lateral resolution (data density)
- Superior accuracy
 - Automatic computation or measurement of reference wave
 - Calculation of mapping errors (pixel scale, distortion)
 - *Reduced cavity lengths for concave mirrors*
- Avoid dedicated nulls for asphere testing
 - Extended non-null test capability
- These benefits can also apply to mid-spatial frequency measurements (in addition to surface form)

The SSI measures parts that a 6" interferometer cannot test


Large numerical aperture

Ø 97 mm R 50 mm




NA: 0.96 (74°)

Ø 92 mm R 48 mm




NA: 0.96 (74°)

Ø 9 mm R 4.5 mm



NA: 1.0 (90°)


Ø 59 mm R 30 mm



NA: 0.98 (79°)



Large clear aperture

Ø 200 mm



R 250 mm

Ø 200 mm
R 500 mm




Non-null test example


- Very mild hyperbola: 3.1 μm departure

(close to the slope limit of a standard interferometer)

Non-null measurement
(spherical reference – measurement is deviation from best-fit sphere, *not* asphere)



Deviation from asphere
(nominal aspheric prescription subtracted from the measurement)



Non-null test issues and solutions



- Fringe resolution
 - Dense fringes cannot be resolved, limiting the amount of aspheric departure measurable in a non-null test
 - Use slower transmission sphere (higher magnification) + stitch
- Retrace error
 - Many fringes in view induce systematic error
 - Automatically model and compensate with stitching
- Remove nominal shape
 - More sensitive to alignment, lateral calibration, and distortion
 - Precise motion + automatic computation + compensation

Increasing measurable aspheric departure: how does it work?

- Magnification is key for resolving dense fringes
 - Simulated fringes for $\sim 50 \mu\text{m}$ aspheric departure
 - Most of the data is unresolvable in the full aperture


Full aperture

67% zone subaperture (& local best-fit sphere)




SSI-A example #1

- Radius ~ -310 mm,
- Aperture 110 mm,
- ~20 μm departure
- ellipsoid





Stitch map (+lattice)
33 subapertures w/ 6" f/3.2

Central subap




Off-axis subap




Example #1 performance data

- Results are both repeatable and have good agreement with a CGH cross-test
 - Higher resolution in stitch map
 - SSI auto-calibrates; CGH calibration more difficult


Stitch repeat #1



Stitch repeat #2




CGH test




SSI-A example #2 (more departure: $\sim 50 \mu\text{m}$)

- Radius $\sim 22 \text{ mm}$
- Aperture 25 mm
- $\sim 50 \mu\text{m}$ departure


Stitch map (+lattice)




35 subapertures w/ 6" f/2.2



Central subap





Off-axis subap



SSI-A example #3 (high quality: <5 nm rms)




- Part manufactured by SSG-Tinsley for a NASA SBIR
 - ~100 mm aperture diameter, base radius ~226 mm
 - Ellipsoid (conic), with ~12 μm of aspheric departure
 - Lightweighted silicon carbide with silicon cladding
 - Used as a secondary mirror for the PICTURE/SHARPI sounding rocket programs



SSI-A™ example 3: test setup

- F/7.2 TS for stitch
 - Lattice #1 balances speed and accuracy
 - Lattice #2 is denser, slightly improving accuracy
- Note: Null test is F/1.5

Subaperture 38 mm off axis



L3-SSG-Tinsley Si-clad SiC EUV M2

Clear Aperture 3.864" Diameter

file : 0322.ca

units: x = mm
y = mm
z = nm
xspac: 0.254
yspac: 0.254
ngx : 511
ngy : 511
gxcen: 0
gycen: 0

z ptv: 24.65
z rms: 3.232

x-apr: 98.04
y-apr: 97.79


z min: -11.85
@ (229, 76)
z max: 12.8
@ (372, 106)
z avg: -0.2896

npnts: 112889/261121


ix : 256
iy : 256
xpos : 0.0000
ypos : 0.0000
r : 0.0000
theta: 0.0000
zval : no data

color: jet

Y+, looking
at optical
surface



Y+ looking
at back of
mirror



12.8



-11.85


(Manufacturer's conic null test over the clear aperture)

Data courtesy of Jay Schwartz.


Example #3 performance data

- Good agreement with existing null test
 - Stitched measurement resolves finer structure

Null test (conic w/ retrosphere)



SSI-A measurement





Larger optics: scaling the SSI®

- Larger parts have slightly different requirements
 - Mechanical distortion of the surface increases with part size
 - Moving (particularly tilting) the part is not desirable
 - Part takes a longer time to thermally stabilize
 - Transmission and nulling optics are not easy to scale up
- Stitching appears extensible to larger optics
 - The workstation needs some changes
 - Increased size and larger X travel
 - Tilt the interferometer, not the part
 - Using a 6" interferometer mainframe is preferred
 - A larger system adds considerable cost!
 - Larger mainframe = harder to move
 - Custom transmission spheres = long lead times

See Mirror Tech Days 2005 presentation on stitching:
http://optics.nasa.gov/tech_days/tech_days_2005/index.html

Larger platform concept



sample concept:
“moving column”



Rough schematics of tilting interferometer

Stitching technology is scalable to larger optics in both vertical and horizontal configurations.

Stitching Redefines the Boundaries



Conclusion:

Stitching boosts all these...
but we'll always want more.



Subaperture stitching interferometry for advanced metrology solutions

Marc Tricard and Paul Murphy

1040 University Avenue, Rochester, NY • USA
+1 (585) 256-6540 • tricard@qedmrf.com •
www.qedmrf.com

Acknowledgements:

Dr. Jim Kirsch – Army RDECOM
Scott Antonille – NASA Goddard